



■ Special Applications

Space Type Gear Coupling




st "S" is the distance between shaft ends. Please give us the further information on "S" when you order.

With Flex Hub on Floating Shaft



With Flange on Floating Shaft



* "S" is the distance between shaft ends. Please give us the further information on "S" when you order.

NOTE) The detail dimensions on the above figures are the same as our original standard size(SSM, SEM, GD, GS)on the page 10 through page 13.