

TIRE

COUPLING



TIRE COUPLING


■ Distinctive Features

1. The *Jac* tire coupling using natural compounds makes couplings suitable for use in most conditions.
2. Handle combinations of parallel, angular and axial displacements.


Parallel displacement(ΔE) : 1% of out dia.

Angular displacement($\Delta \theta$) : within 2°


End float(Δd) : within -10% and +3% the width of the coupling.






Paralled displacement




Angular displacement



End float




3. Mounting-Demounting. Installation is quick and easy. No special tools needed.




4. Reduce Torsional Vibrations.
Absorb shock Loads.
5. After Installation,
Eliminates the need for lubrication.
No dismounting needed for inspection of components.
6. Damping.
Reduce Vibrations and torsional oscillations.

■ Dimensions




Size	Rating Torque (kgf · m)	Max. r.p.m	Tire				Flange				G		W	Bolt 2 × n-d × p × l	GD ² (kgf · cm ²)	Weight (kg)
			A	B	C	D	E	F	H	I	Min. Bore	Max. Bore				
JAC-100	5	5000	100	35	37	50	82	36	28	6	8	22	93	2 × 6-M6 × 1.0 × 20	34.9	1.1
JAC-120	10	4500	120	45	39	65	106	48	35	6	10	28	109	2 × 6-M8 × 1.25 × 20	78.4	2.0
JAC-140	15	4200	140	52	45	75	118	55	44	7	24	35	133	2 × 6-M10 × 1.5 × 25	164.6	3.0
JAC-160	22	4000	160	62	51	85	132	65	53	8	24	42	157	2 × 6-M10 × 1.5 × 25	301.8	4.5
JAC-185	30	3600	185	74	58	100	154	77	60	10	34	48	178	2 × 6-M12 × 1.75 × 25	568.4	6.6
JAC-220	50	3200	220	84	67	112	180	89	69	12	34	55	205	2 × 6-M12 × 1.75 × 30	1293.6	11.8
JAC-265	100	2600	265	112	82	140	214	117	94	14	40	75	270	2 × 6-M12 × 1.75 × 35	3802.4	21.7
JAC-340	165	2100	340	142	106	180	272	150	120	18	44	95	346	2 × 6-M16 × 2.0 × 45	12544	46.5
JAC-445	500	1600	455	190	139	236	344	202	160	25	54	128	459	2 × 6-M18 × 2.5 × 55	44688	110
JAC-550	1000	1200	550	230	173	290	430	246	170	26	64	170	513	2 × 8-M24 × 3.0 × 70	125440	187
JAC-700	2000	1000	700	310	220	370	544	326	220	26	84	220	660	2 × 12-M24 × 3.0 × 70	356720	394

■ Installation



With tire, connect coupling flanges to driving and driven shaft. Now mount the tire and tighten the clamping screws gradually, until the specified tightening torque is reached.



 **Jac coupling**

HOME PAGE [http : // www.jacoup.co.kr](http://www.jacoup.co.kr)
E-mail : jac@jacoup.co.kr